

# REALISTIC MAGNETIC BULK TAPE ERASER - CAT. NO. 44-2

UL  
APPROVED

## INSTRUCTIONS: TO ERASE REELS OF TAPE, CASSETTES, CARTRIDGES:

1. Plug in standard outlet, 110-115 V. A.C. only.
2. Hold unit in hand as per illustration with thumb resting on switch button at side of handle, and press ("ON").
3. While switch is "ON", place bottom of Eraser in contact with Reel of Tape, Cartridge, or Cassette. Move Eraser in circular motion over entire area of tape. On Reels, work from center to outside. Approximate time 7 to 10 seconds. **DO NOT RELEASE SWITCH BUTTON.** Erasure for longer periods is not required, but will not do any harm.
4. With button still depressed, slowly move Eraser to a distance of 3 ft. up and away from tape. Then release button.
5. To erase magnetic striped sound track on film, place reel with magnetic track up and proceed as per steps 3 and 4.

## INTERMITTANT DUTY:

1 MIN. ON - 20 MIN. OFF. DO NOT EXCEED.

It is normal for this unit to get slightly warm during use. Therefore, after 1 minute of continuous or combined use (the time the switch is actually depressed), permit unit to cool for 20 minutes to prevent overheating.

**CAUTION:** When in use, keep Eraser away from delicate and electronic watches, **CARDIAC PACE MAKERS**, as well as other recorded tapes or film.

CUSTOM MANUFACTURED IN U.S.A. FOR RADIO SHACK  
A DIVISION OF TANDY CORPORATION, FORT WORTH, TEXAS 76102

