



SPACE SAVER DESK

Catalog Number 26-1304



H
A
R
D
W
A
R
E





ASSEMBLY INSTRUCTIONS

- STEP 1** - Open carton and remove all parts. Place **Top (Item No. 1)** upside down inside carton.
- STEP 2** - Using eight (8) **½" Screws (Item No. 2)** attach **Legs (Item No. 3)** to top. Do not tighten screws all the way.
- STEP 3** - Using four (4) **2½" Screws (Item No. 4)** attach **Modesty Panel (Item No. 5)** to legs and tighten all screws.
- STEP 4** - Tap **End Caps (Item No. 6)** and screw **Levelers (Item No. 7)** into legs. Turn desk over and place in desired location, level desk by rotating levelers until desk is stable. Desk assembly is now complete and ready for use.

CAUTION TO USER: The TRS-80 Space Saver is a physically light-weight table, and a complete TRS-80 System used with it produces a fair amount of weight with a high center of gravity. Caution operators to be careful not to "bump" the table hard enough to cause the equipment to fall. Whenever possible, if the table can be positioned with its back to the wall, the danger of knocking the equipment off the table will be minimized.

PARTS LIST

<u>ITEM NO.</u>	<u>DESCRIPTION</u>	<u>QUANTITY</u>
1	Top Shelf	1
2	½" Long Screw	8
3	Legs	2
4	2½" Long Screw	4
5	Modesty Panel	1
6	End Caps	4
7	Levelers	4

LIMITED WARRANTY

For a period of 90 days from the date of delivery, Radio Shack warrants to the original purchaser that the computer hardware described herein shall be free from defects in material and workmanship under normal use and service. This warranty is only applicable to purchases from Radio Shack company-owned retail outlets and through duly authorized franchisees and dealers. The warranty shall be void if this unit's case or cabinet is opened or if the unit is altered or modified. During this period, if a defect should occur, the product must be returned to a Radio Shack store or dealer for repair, and proof of purchase must be presented. Purchaser's sole and exclusive remedy in the event of defect is expressly limited to the correction of the defect by adjustment, repair or replacement at Radio Shack's election and sole expense, except there shall be no obligation to replace or repair items which by their nature are expendable. No representation or other affirmation of fact, including, but not limited to, statements regarding capacity, suitability for use, or performance of the equipment, shall be or be deemed to be a warranty or representation by Radio Shack, for any purpose, nor give rise to any liability or obligation of Radio Shack whatsoever.

EXCEPT AS SPECIFICALLY PROVIDED IN THIS AGREEMENT, THERE ARE NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND IN NO EVENT SHALL RADIO SHACK BE LIABLE FOR LOSS OF PROFITS OR BENEFITS, INDIRECT, SPECIAL, CONSEQUENTIAL OR OTHER SIMILAR DAMAGES ARISING OUT OF ANY BREACH OF THIS WARRANTY OR OTHERWISE.

RADIO SHACK  A DIVISION OF TANDY CORPORATION

U.S.A.: FORT WORTH, TEXAS 76102
CANADA: BARRIE, ONTARIO L4M 4W5

TANDY CORPORATION

AUSTRALIA

280-316 VICTORIA ROAD
RYDALMERE, N.S.W. 2116

BELGIUM

PARC INDUSTRIEL DE NANINNE
5140 NANINNE

U. K.

BILSTON ROAD WEDNESBURY
WEST MIDLANDS WS10 7JN