

FREHD CABLE INSTALLATION MODEL III/MODEL 4 (NGA) WITHOUT SERIAL BOARD INSTALLED

Remove metal shield (if you have one) to expose your motherboard
Disconnect the keyboard cable, cassette cable, power cable and video cable (**see ARROWS**)
Remove the (8) screws (**see CIRCLES**). Your machine should now look like **FIGURE 2**
Route the 50 pin cable as shown (**FIGURE 3**) making sure **RED PIN STRIPE FACES LEFT**
Attach **CARD EDGE CONNECTOR TO MOTHERBOARD (FIGURE 4)**
Re-attach motherboard to chassis and re-connect all connectors (**FIGURE 5**)
You can now attach your FREHD to the cable as desired (**FIGURE 6**)

