

USING THE ROM LOADER
(Information for Model 4 Users)

The Radio Shack Network 3 ROM Loader lets you load the Network 3 Student Station System Software directly from the Host computer disk through the Network 3 Controller and into the Student Stations. This eliminates the necessity of using a cassette player or a Network 2 Controller to load the software.

Model 4 machines with catalog number 26-1059 already have the ROM Loader; otherwise the Loader must be installed at a Radio Shack Service Center or Repair Center. After the ROM Loader is installed, the Model 4 will function normally as a stand-alone computer. To make the Model 4 function as a Student Station, follow the steps below. (These replace steps 1 through 15 on pages 3-6 of the Network 3 Operating Software User's Manual.)

1. Follow steps 1-3 on page 3 of the User's Manual.
2. **At the Host Computer**, follow steps 11-15 on page 5 of the User's Manual. However, note an important difference when you have completed step 15: The top line of information displayed on the screen must contain the number "1.1" or a larger number for the ROM Loader to operate. If the number displayed is "1.0", you need to get a later version of the operating software.

3. At each Student Station

When the screen shows:	You type:
Cass?	<ENTER>
Memory Size?	<ENTER>
Ready >	SYSTEM <ENTER>
*?	/12363 <ENTER> (Student Station will now load from the Host disk.)
Baud rate?	<ENTER>

The Student Station should now display the "Network 3" prompt. Now, continue at step 16 on page 6 of the User's Manual.